

Ultra-Flex Bird Spike Installation


Long-lasting Ultra-Flex Bird Spikes provides decades of maintenance-free protection. Never rusts or deteriorates. It just does the job without marring the look of your property.

It's practically invisible.

Flexible Spikes Mount easily on flat, curved or irregular surfaces - whether wood, metal or masonry.

EASY TO INSTALL

Ultra-Flex 24" sections attach quickly with caulking, silicone, adhesive, nails, screws, wire or plastic ties, etc.



1-877-4-NO-BIRD
www.pigeonpatrol.ca

Special thanks to the people and companies that helped in gathering this information.
This information is to be used as reference only.

Additional Netting Installation Methods

Different ways to get the desired results - No Birds!


The details below provides examples of 'additional methods' that can be used to install bird exclusion netting. Before installing, make sure that the method you use will achieve the desired results - no gaps, tears, wrinkles or excessive sag in the netting fabric.

Staple, Roll, Install

For flat surfaces, staple the edge of the bird netting to a 1x2 (wood) then roll the 1x2 in the netting 2 or 3 times. Apply a bead of latex based sealer* to the back of the 1x2 and fasten it to the surface.


Allow at least an extra foot of netting on all sides of the net so each side can be stapled, rolled and installed.

Staple..




Staple every 3"
Allow extra net
at ends of 1x2

Roll..



ALWAYS roll
the 1x2 in the netting. Apply
a bead of sealer* to the back
of the 1x2 before installing.

Install.



Install with
the appropriate hardware


Pre-drill 1x2 for faster installation. Drawings are examples - your installation may be different

Netting Frames

A simple frame can be used to secure bird netting. If using wood, follow the 'staple, roll, install' steps shown above. Other framing materials can be substituted for wood.


Frames can be used for flat and straight sided areas. For areas that have curves and many corners

Eaves & Overhangs




Frame above & below,
enclose with net, seal
seams with Twist Locks

Structural Openings



Frame around perimeter
of openings. Make sure frame
ends up inside installed net.

Small Enclosures



Protect plants
& small gardens from birds.


Drawings are examples - your installation may be different.

Wood On Steel

Use for flat steel surfaces only. Wood 'nailers' can be fastened to structural steel beams to make netting installations on structural steel easier and faster.


Boards can be securely fastened to steel surfaces using less hardware than if the netting were fastened directly to the steel surface.

Fasten to steel




Fasten to steel with proper
hardware every 24" o.c.

Sandwich Netting



Sandwich netting between,
secure with wood fasteners

Vertical Beams



The process is the same for
vertical beams and steel.

Drawings are examples - your installation may be different.



1-877-4-NO-BIRD
www.pigeonpatrol.ca

Special thanks to the people and companies that helped in gathering this information.
This information is to be used as reference only.

Bird Netting Enclosure Examples


The drawings below are examples. Your installation may be different.

Eaves & Overhangs


Closes off sheltered areas under eaves and overhangs. Clean the area thoroughly. Enclose the area from the edge of the roof down to the wall. The wider the overhang, the farther down the wall the netting must run.

Using the proper fasteners, net off the open ends and close up all netting seams.


Plan Netting Path



Install Netting



Seal Ends & Seams




Dormers

Protects the sheltered areas where a dormer roof overhangs the main roof.


Thoroughly clean the area. Install the netting in 2 pieces as shown. Use the fastening method that best suits the installation surfaces. Close seam at outside corner.

Protect both sides of dormer.


Plan Netting Path



Install Side Netting



Seal Front & Seam




Awnings

Keep birds out from under awnings, canopies and covered walkways.

Clean all areas thoroughly. Determine the best route for the bird netting.

Use fastening system that allows for access behind netting and best suits the installation surfaces.


Plan Netting Path



Install Netting



Large Awnings




Net Cover & Curtain


Cover vertical walls to keep birds off of complex surfaces. If birds can get to both sides, cover both sides with netting.

Curtain installations help keep birds from flying through openings where a solid barrier is not practical. Use the draw top or fixed top methods shown.

Wall Cover Netting



Curtain - Draw Top



Curtain - Fixed Top



1-877-4-NO-BIRD
www.pigeonpatrol.ca

Special thanks to the people and companies that helped in gathering this information. This information is to be used as reference only.